# wwHD VIDEO CONVERTER

### User Manual

## MINI CVBS TO HDMI Converter

Bring High-Definition to your life

### 1.0 INTRODUCTION

The MINI AV TO HDMI converter is a universal converter for analog composite

input to HDMI 1080p (60HZ) output. The analog to digital conversion in this module employs 10 bits maximal 162MSPS sampling, black/white level expansion, color transition improvement, dynamic range expansion, blue stretch, auto-detect and auto-convert the composite signal to 1080p(60HZ) output. Making video come alive, delivering the sharpest, most realistic HD visuals available.

#### 2.0 FEATURES

- 1. No need to install drivers, portable, flexible, plug and play;
- 2. Provide advanced signal processing with great precision, colors, resolutions, and details:
- 3. Support PAL, NTSC3.58, NTSC4.43, SECAM, PAL/M, PAL/N standard TV formats input;
- 4. Support HDMI 1080p or 720p output.

#### 3.0 SPECIFICATIONS

- 1. Input ports:3xRCA (Yellow, White, Red);
- 2. Output ports: 1xHDMI;
- 3. Dimensions (mm): 66(D) x55(W) x20(H);
- 4. Wight (g): 40;
- 5. Composite input: PAL, NTSC3.58, NTSC4.43, SECAM, PAL/M, PAL/N;
- 6. HDMI output: 1080p60Hz, 720p/60Hz.

#### 3.0 PACKAGE CONTENTS


Before attempting to use this unit, please check the packaging and make sure the following items are contained in the shipping carton:

- 1) Main unit (AV TO HDMI Converter)-----1PCS
- 2) USB Cable or 5V 1A Power adapter-----1PCS
- 3) User Manual-----1PCS

#### **4.0 PANEL DESCRIPTIONS**

Please study the panel drawings below and become familiar with the signal

input(s), output(s) and power requirements.



#### **5.0 CONNECTION DIAGRAM**

#### **WARNING**

1. Do not expose this apparatus to rain, moisture, dripping or splashing and

- that no objects filled with liquids, such as vases, shall be placed on the apparatus.
- 2. Do not install near any heat sources such as radiators, heat registers, Stoves or other apparatus(including amplifiers)that product heat.
- 3. Do not place sources of naked flames, such as lighted candles, on the unit.
- 4. Clean this apparatus only with dry cloth.
- 5. Only use attachments/accessories specified by the manufacturer.
- 6. Refer all servicing to qualified service personnel.