HD AUDIO CONVERTER

Analog to Digital audio converter

Bring High-Definition to your life!

Dear Customer

Thank you for purchasing this Audio Converter. For optimum performance and safety, please read these instructions carefully before connecting, operating or

adjusting this product. Please keep this manual for future reference.

1.0 INTRODUCTION

This Analog to Digital Audio Converter is designed for either home or professional audio switching. It converts analog stereo audio signal from R/L input to Coaxial and Toslink outputs simultaneously. The output digital audio signal is 2-channel uncompressed LPCM (Linear Pulse Code Modulation) with sampling rate at 48 KHz. This Converter is small in size and quite easy to install.

2.0 FEATURES

This Converter has many features that enable it to perform in a superior manner. Among those features you will find:

- 1. Supports uncompressed 2-channel LPCM digital audio signal output.
- 2、Supports output sampling rate at 48 KHz.
- 3. Provides electromagnetic-noise-free transmission.
- 4、Easy to install and simple to operate.

3.0 SPECIFICATIONS

Stereo R/L
LPCM
2XRCA (R/L)
Toslink、1XRCA(Coaxial)
Toslink Audio and Digital Audio
48KHz
50X40X35MM
78g
1 Year Parts and Labor
0 ℃ to +70℃
10% to 85 % RH (no condensation)
-10℃ to +80℃
5% to 90 % RH (no condensation)
5V DC@1A
0.5 watts (max)

Converter Unit	FCC,CE,UL
Power Supply	UL,CE,FCC
Accessories Adapter	
AC Power Adapter	US standard, UK standard and so on
User Manual	English Version

Note: Specifications are subject to change without notice.

4.0 PACKAGE CONTENTS


Before attempting to use this unit, please check the packaging and make sure the following items are contained in the shipping carton:

- 1) Main unit (Analog to Digital Audi Converter).
- 2) 5V DC Power Supply.
- 3) User's Manual.

5.0 PANEL DESCRIPTIONS

Please study the panel drawings below and become familiar with the signal input(s), output(s) and power requirements.

Back Panel Upper Panel Front Panel



6.0 CONNECTION AND OPERATION

Before installation, please make sure all devices you wish to connect have been turned off.

- 1) Connect the audio source device to the Converter using appropriate R/L cable.
- 2) Connect the A/V Receivers or Amplifiers to the Converter using appropriate Toslink or Coaxial cables.
- 3) Insert the DC side of 5v power supply into the converter and then connect the AC side of the power supply into the wall outlet.

Attention: Insert / Extract cable gently.

7.0 CONNECTION DIAGRAM

